Other locking

Adams Rite 6201 Flushbolt



Application:

The Adams Rite 6201 Flushbolt is used for securing the slave leaf of a pair of doors. Standard installation requires two flushbolts, morticed into the top and bottom of the door.

Specification:

- Suitable for use on aluminium doors.
- Flat or radius
- Operating lever is hidden when doors closed
- Satin chrome finish
- Hardened steel bolt, zinc plated with anti-rattle sleeve





Variants:

Code	Description
6201-01	6201 FLUSH BOLT GUIDE
6201-6-12	6201 FLUSH BOLT FLAT, SAA 12 ROD
6201-7-12	6201 FLUSH BOLT RDS, SAA 12 ROD
6201-R20	20" ROD TO SUIT 6201 FLUSHBOLT